

Model A - Pre-Season Check List

	Yes	No		Yes	No
Power train			Steering & Suspension		
Change oil at least one a year, check level			Steering box; check for excessive wheel play		
Transmission; check oil level, change if necessary			Steering box; adjust if needed, check fluid		
Distributor; check timing & point gap			Steering box bolts to frame - tight & cottered		
Distributor; lube shaft (2 places) & cam			Pitman arm; check for tightness		
Coil; clean & check wire, check nuts for tightness			Tie rod & drag link; check for tightness		
Spark plugs; remove, clean, inspect, adjust			Spindle play; raise front end & check		
Spark plugs; check wires - snug w/some tension			Check all cotter pins on front axle		
Battery; check fluid level, clean terminals			Tie rod properly installed, tighten up, & lubed		
Carburetor; drop bowl & clean, clean filter			Front spring; space between shackle & axle		
Fuel; check for leaks, check/clean gas bulb					
Wiring, check for bare areas & proper support			Brakes		
Fuses; check, replace if needed			Properly adjusted - all 4 wheels		
Fan; check for bends/cracks, tightness to shaft			Emergency brake - locks at 3rd notch		
Fan belt; check tightness & condition			Brake pedal free travel 1" - 2"		
Radiator; check hoses, check system for leaks			Brake Rods are straight		
Radiator; check fluid level, clean debris from fins			All clevis pins & cotter pins properly installed		
Generator; check amp meter for charge, adjust			Front level arms - 15° forward tilt		
Water pump; check for leaks, end play, lubricate					
Throttle linkage; check for bends & returns freely			General		
Exhaust system; check for tightness & leaks			Horn; check operation, clean & adjust		
Clutch; check for 1" of free play			Windshield wiper; check operation		
Clutch level; adjust if needed; check cotter pin			Windshield; Apply RainX		
Rear axel; check fluid level, check banjo bolts			Ensure doors latch properly		
			Fire extinguisher charged		
Wheels			Flashlight operational		
Lug nuts; properly tightened, 50-55 ft-lbs			First-aid kit		
Tire Pressure; check for 35 PSI			Tool kit		
Tire condition; 1/8" min tread depth, cracks					
Front wheel bearings; clean, inspect & repack			Lubricate (grease/oil)		
Rear wheel bearings; clean, inspect & repack			Spring shackles; front & rear		
Wheel condition - bent/cracked spokes, wobble			Throw out bearing		
			Clutch & brake pedals		
Lights			Brake backing plates; front & rear		
High & low beams; check operation & alignment			Shocks		
Taillights & stop lights; check operation			Tie rod		
Turn signals; check operational			Drag link		
			Universal joint		
			Brake cross shaft		
			Distributor		